BEYOND BATTERIES

TECHNICAL DATA SHEET Micro Opti Module 8KWH-48V EN-8k-48-1C-2PA-X-X-RIB_1V0_GEN1

VERSION 1 | REVISION 0 | RELEASE DATE: 25th Sept 24



EFFICIENT

- Highly Efficient: > 95% RTE (Round Trip Efficiency)
- 100% DOD (Depth of Discharge)
- 500,000 Cell Life Cycles



SAFE & RELIABLE

- Wide Operating Temperature Range
- Deployable in Various Environments including High Altitudes
- No Thermal Runaway Risk

TECHNICAL DATA SHEET

EN-8k-48-1C-X-X-X-PIB_1V0_GEN1

PERFORMANCE SPECIFICATIONS

DC Energy	8kWh	
Voltage Range	43.2Vdc to 60.8Vdc	
DC Voltage (Nominal)	48Vdc	
Internal Resistance	< 4 mili Ohms	Front View
CELL SPECIFICATIONS		
Technology	Encapsulated Cell	
Nominal Cell Voltage	6.4 ~6.6Vdc / Cell (Encapsulated) 1/2 + 0.12V Envelope	
CHARGE CHARACTERISTICS		
Maximum Continuous Charge Current	170A (~1C)	Isometric View
Charging Method	CC/CP/VP	
DISCHARGE SPECIFICATIONS		
Maximum Continuous Discharge Current	170A (~1C)	
Discharging Method	CC/CP/VP	
EN-CONNECT SOFTWARE ²		
Module Monitoring ²	Total Voltage, Individual Cell Voltages, Current,	
	Temperatures, SOC and Energy Consumed	
MODULE ENVIRONMENTAL SPE	CIFICATIONS	
Operating Temperature Range	-30°C~ +70°C	ENCONTROL ²
Operating Humidity	Non-Condensing	

Page 2/4

TECHNICAL DATA SHEET

EN-8k-48-1C-X-X-X-PIB_1V0_GEN1

MECHANICAL SPECIFICATION	١٥	
Dimensions ¹ (W x H x D) mm	482 x 134 x 568	
Weight (kg)	43	- <u>•</u> •
Module Casing Material	GI Powdered	Front Vie
Terminal Type	300A Terminal Post	
SMART FEATURES		
Circuit Breaker Protection	2P 125A Breaker	
OLED Display (With Encontrol) ²	Monitor Module	
Communication	CANBUS , RS232, RS485	Isometric Vi
Alarm ²	Buzzer alarm in the event of Over/under-Voltage, Over-	
	Current, Over Temperature	
Dry Contacts Output	Programmable Dry Contacts	568
SAFETY PERFORMANCE		Side View
Short Circuit Protection	Through MCB and Encontactor	
Over/under Voltage	Through Encontactor	
Over Current	Through MCB and Encontactor	
Over Temperature	Through Encontactor	
SERVICE LIFE		
Cells Projected Cycle Life ³	500,000 cycles	440.00
Cells Projected Calendar Life ⁴	25 years	482.60
		Top View

TECHNICAL DATA SHEET

EN-8k-48-1C-X-X-X-PIB_1V0_GEN1

Module Projected She	elf Life ⁵ 10 years	NOTES
Warehousing	Can be stored at any SOC without affecting cycle life	¹ Product Dimensions are for reference only and may change with
PRECAUTIONS		notice. ² The ENCONTROL tool is an OLED display designed for Module
Alarm	In case of alarm, immediately rectify/attend to the cause of the alarm.	monitoring. Please note SMART FEATURES are not part of the
Physical Damage	In case the Module is physically damaged due to any event, do not install and energize the Module under any circumstances and contact your	standard Module and require separate purchase of ENCONTROL tool.
	Reseller or After Sales Support.	 ³ Projected Life of encapsulated cells. ⁴ Projected Calendar Life of encapsulated cells from the date
Short Circuit	Ensure precautions to prevent short-circuit under all circumstances.	first operation.
Galvanic Isolation	When connecting to external devices ensure that galvanic isolation of the	⁵ Shelf Life is the Life of the Module (in years) from the date it manufactured to the time it is first operated.
	external device(s) does not exceed 1000V.	manufactureu to the time it is hist operateu.
Series Connection of eight (8) connected i	All Modules must be at 100% SOC before connecting in series. Maximum	
	of eight (8) Modules can be connected in series. Modules can only be	 Additional terms and conditions, including a limited warrant
	connected in series through Encontactor and en controller refer to ENRack	will apply at the time of purchase.
	for better performance.	For critical applications, please contact your Reseller or Af
ŀ	All Modules must be at 100% SOC before connecting in parallel.	Sales Support.
Parallel Connection	There is no limit on the number of Modules that can be connected in	Encap Micro Opti must be operated with Encontactor a
parc	parallel.	Encontroller, otherwise there is risk of severe damage. Plea
Series-Parallel	Series-Parallel Connection Modules can be connected in series-parallel	refer to the Enrack user manual or contact the technic
	combination through Encontactor and encontroller refer to ENRack for	support team for further guidance.
Connection	better performance.	